



Authentic Adventure Gear®

INSTRUCTIONS

Item 01113

Hide-A-Way Camo Hexagon Dome Tent

Thank you for purchasing this Texsport tent. Please read and understand each step of the set-up instructions. We encourage you to set-up this tent at least once prior to your camping trip, ensuring that you have a satisfactory understanding of the set-up process. We hope you enjoy your new tent and that it will give you many years of camping pleasure.

Do not apply excessive force to this product.

PARTS LIST:

A3 Sets of tent poles


BTent skin

CRainfly

DStakes

NOTE:

Prepare your camp site by removing all sharp stones, twigs, etc. The site should be flat and have no depressions that could collect rain water.



STEP 1 - Spread out tent skin.



STEP 2 - Assemble the tent poles (A) and insert through the tent sleeves.



STEP 3 - Your poles should form a "star" as shown above.



STEP 4 - Insert the pin and ring into the tent poles.



STEP 4 - Secure tent to poles with attached toggle.



STEP 5 - Stake down at the ring on all corners.



STEP 6 - This is what your tent should like without the rainfly.



STEP 7 - Drape the rainfly over the tent and secure it by attaching the fly hooks onto the loops on the tent.



STEP 8 - This is what your tent should like with the rainfly.