


ASSEMBLY INSTRUCTIONS


Item 15161 - Compact Camp Kitchen

Thank you for buying a Texsport Authentic Adventure Gear Product. We hope you enjoy your new table and that it will serve you with many years of camping pleasure. We encourage you to read and understand each step of the set-up instructions prior to working with the table.


PLEASE FOLLOW THE SEQUENCE OF IMAGES TO ASSEMBLE YOUR TABLE.




These are the parts you will need to assemble your table.




Expand table frame to open position.




Slide P.V.C. sink onto suspension arms and snap into brackets.



Clamp rubber coated supports onto suspension arms as indicated.



Attach the mesh drying net/utility shelf to the hooks on the main table legs.




Swing main suspension arms into support brackets.



Snap table top over suspension arms.



Insert the wire utility rack into the slots on either side of the table handles (as shown above). Be sure it is pushed fully into place



Assemble lantern pole and inset into support stanchion and secure tightly. Extend top lantern hanger.

QUESTIONS: If you should have any questions, problems or comments, please call our Customer Service Department at 1-800-231-1402. This Department is open M-F from 8 a.m. – 5 p.m. C.S.T.

MODEL: COMPACT
CAMP KITCHEN
ITEM # 15161
MADE IN CHINA