


Thank you for purchasing this Texsport shower/shelter. Please read and understand each step of the set-up instructions. We encourage you to set-up this shower/shelter at least once prior to your camping trip, ensuring that you have a satisfactory understanding of the set-up process. We hope you enjoy your new shower/shelter and that it will give you many years of camping pleasure.

**Do not apply excessive force to this product.**



**Parts List:**

- A ..... 1 Shower/shelter skin
- B..... 2 Towel holder poles
- C..... 4 Leg poles
- D ..... 4 Curved roof poles
- E..... 4 Eave poles
- F..... 1 Molded roof joint
- G ..... 4 Molded corner joints

- H ..... Solar shower
- I..... Stakes, clews, and guy rope
- J..... Towel holder straps
- K ..... Removable floor

**NOTE:**


Prepare your camp site by removing all sharp stones, twigs, etc. The site should be flat and have no depressions that could collect rain water.



**Note:** All frame poles have a locking tab. Line up the tab and slot on each pole for a secure fit.



**Step 1 - Assemble the curved roof poles (D) and insert each one into the molded roof joint (F).**




**Step 2 - Make sure all curved roof poles are secure as shown above.**




**Step 3 - Insert the curved roof poles into the molded corner joints (G).**



**Step 4 - Assemble the eave poles (E) and insert each one into the molded corner joint.**



**Step 5 - Make sure all poles have snapped into their locking tab for a secure fit as shown above.**



**Step 6 - Assemble ONLY the top 2 sections of the leg poles (C). The top section will have a small hole.**



**Step 7 - Insert the top section of the leg poles into the bottom sockets of the molded corner joints.**



**Step 8 - This is what your frame should look like at this point.**



**Step 9 - Spread the shower/shelter skin and locate the web loop at the top of the skin.**



**Step 10 - Hook the web loop onto the molded roof joint.**



**Step 11 - Attach the speed clips to the frame.**



**Step 12 - This is what your frame should look at this point.**



**Step 13 - Connect the last section of the leg poles and insert the pin and ring into the bottom of each leg pole.**



**Step 14 - Stake down all 4 sides of the shower/shelter at the rings.**



**Step 15 - This is what your shower/shelter should look like without the fly or other accessories.**



**Step 16 - Drape fly over shower/shelter and insert the attached hooks into the small holes on the leg poles as shown above.**



**Step 17 - This is what your shower/shelter with fly should look like.**



**Step 18 - Secure your shower/shelter combo by using guy ropes. Insert the guy rope into the clews and knot the end as shown above.**



**Step 19 - Tie the other end of the guy rope onto the fly loops.**



**Step 20 - Loop the guy rope around a stake and insert into the ground.**



**Step 21 - Slide the clew up or down the guy rope to adjust the tension.**



**Step 22 - Attach the towel holder straps (J) onto the shower/shelter side roof poles with the speed clips.**



**Step 23 - Insert a towel holder pole (B) into the loops on the straps.**



**Step 24 - Hook the camp shower from the attached hook inside shower/shelter as shown above. You can also use the rope included.**



**Step 25 - To attach the shower caddy inside, insert the toggle into the ring.**



**Step 26 - Secure all toggles through the rings as shown above.**



**Step 27 - To attach the removable floor, clip at the bottom of the shower/shelter web loops.**

**WARNING:** Texsport shelter fabrics are flame retardant treated per C.P.A.I.-84 specification. However, for your safety, we recommend that NO OPEN FLAME BE USED IN OR NEAR YOUR SHELTER.

**SOME ADDITIONAL INFORMATION:**

Always secure your shelter (with the shelter stakes included). Stake one corner, then stake each consecutive corner in a clockwise rotation. Make sure the shelter remains tight. Always place your shelter a safe distance from your campfire - unstaked shelter placed upwind of the fire can be blown into the fire. Shelter placed downwind of the fire are often showered with tiny sparks that can burn holes into the lightweight fabrics of your shelter.

**WATERPROOFING YOUR SHELTER:**

Texsport shelters are made from coated water-repellent fabrics. However, the sewing process, necessary in all shelter fabrication, can cause water leakage where the sewing needles have perforated the fabric in the seams. Without treatment the shelter will leak. Every new shelter needs to be seam sealed to make it water tight. We recommend using Texsport Spray Waterproofing/Seam Sealer which may be found

at your local outdoor outfitter or camping store. DO NOT APPLY SEAM SEALER TO ZIPPERS.

**STAKES:** All shelters should be staked down. The stakes supplied with your shelter are effective for most conditions; however, specialized stakes are recommended in certain cases:

- a. Sand Stakes: Long broad stakes designed to hold in loose sand.
- b. Steel Stakes: Most effective in hard, rocky or frozen soil. These can rust and their sharp edges could damage the shelter if stored with the shelter. In extremely hard soil a steel rod can be used to make the starter hole.
- c. Skewer Stakes: Lightweight, but less holding power than the standard stakes.
- d. Snow Stakes: The most common method is to bury objects with a great deal of surface area in the snow i.e. branches, aluminum pie plates, stuff sacks or shelter bags filled with snow and buried: (this may be referred to as the dead man method). Shelters can also be secured to snow skis or poles which are stuck into the snow.

**ZIPPERS:** If zippers stick, lubricate with silicone. Never force a zipper which has material caught in it as this will bend the slider and prevent the zipper from closing. Continual use in a sandy environment can cause the slider to erode and fail to close the zipper.

**STORAGE:** Shelters should be stored dry and loosely folded away from heat and water. Keep out of reach of mice as they like to nest in shelters. Never store directly on concrete as moisture and chemicals in concrete may damage the nylon.

**WASHING:** Hand wash with a sponge using a mild soap. Never use detergents or washing machines as they may damage the coating or seams. Remember to use seam sealer once shelter has been washed to insure waterproofing.

How long will a nylon shelter last?

Various conditions will affect the length of service which you receive:

- a. A nylon shelter which is left erected all summer may last only one or two seasons as the sun's ultra-violet rays damage the nylon.
- b. Never store a shelter wet or damp as mildew may develop. It will not harm nylon, however, mildew is unsightly and may damage other parts of the shelter (i.e. zipper tapes)
- c. Avoid spraying insect repellent or hair sprays, etc. on shelter fabric as they may be harmful.

**REPAIRS:** For small tears use an adhesive backed rip-stop nylon patch. We recommend Texsport Nylon Shelter Repair Kit (#14113) which may be found at your local outdoor outfitter or camping store.

**QUESTIONS:** If you should have any questions, problems or comments, please call our Customer Service Department at 1-800-231-1402 or e-mail info@texsport.com. This Department is open M-F from 8 a.m.-5 p.m. CST.